OPERATION:

Grasp both switch handle and front knob handle firmly. Turn tool "ON" and use tool freely without forced effort or excessive pressure. In most cases, the weight of the tool will provide sufficient pressure.

Move the sander in any direction over the work area. (When sanding wood, it is not necessary to sand only with the grain). Sand only long enough to obtain a smooth surfacecutting action is rapid and too much material may be removed by prolonged sanding.

For best results in wood sanding, sand first with coarse paper, then with medium paper, and last with fine paper. To obtain an exceptionally smooth surface, wet the wood with a rag or sponge and let the wood dry. The grain of the wood will then raise slightly and the surface will feel rough. Resand with B&D 150 or 4/0 grit paper for extra smooth results.




Fig. 2

FACTORY SALES and SERVICE CENTERS

Area Telephone Area To Code No. Code	elephone No.
000	T 4-6220
ALABAMA 35233, Birmingham, 1717 Third Ave., So205 324-6691 NEW YORK 14209, Buffalo, 881 W. Delavan Ave716 T ARIZONA 85007. Phoenix. 537 E. McDowell Rd602 AL 8-1332 10462, New York, 1894 E. Tremont Ave. (Bronx)212 S	Y 2-2700
	A 9-6450
	E 5-1042
	454-3814
	446-3086
	R 5-3721
	125-1181
95050, Santa Clara, 2291 The Alameda	275-4487
	421-2275
	L 1-4243
CONNECTICUT 06:114, Hartford, 131 Meadow St203 249-6241 43202, Columbus, 3293 N. High St	M 8-5797
FLORIDA 32208, Jacksonville, 5224 Pearl Street904 836-8351 45420, Dayton, 617 Watervliet Ave513	252-1821
33147, Miami, 2075 N. W. 54th Street305 356-2951 44139, Solon, 6225 Cochran Rd216 C	H 8-5330
32806, Orlando, 940 So. Orange Ave	475-6771
33609. Tampa, 3407 S. Dale Mabry Hwy	E 2-7515
GEORGIA 30313 Atlanta, 316 Techwood Dr., N.W., 404 JA 4-0431 74114, Tulsa, 2602 So. Harvard St., 918	747-1558
HAWAII 96813, Honolulu, 675 Auahi St808 569-374 OREGON 97209, Portland, 1640 N.W. Johnson St503 C	A 8-8631
ILLINOIS 60607. Chicago, 1100 W. Jackson Blyd312 TA 9-3500 PENNSYLVANIA 17112, Harrisburg,	
60646 Chi Lincolny'd 6710 N. Crawford Ave312 OR 3-0923 6070 Allentown Rd	(15-0651
	X 3-5831
	0 4-5520
40207, Illulaliapolis, 1120 W. 10th Oct.	362-2700
IOWA 50312, Des Moines, 2811 Ingersoll Ave	***
NAMOAO U/214, WICHITE, 200 HO. MICHEWOON CL	434-1655
	232-3038
LUUISIANA / UTIZ, NEW UTICANS, 2010 TOYUTAS SU	546-2481
MARTERIO ETETT, Dartimore, 200 II. 20th Commission III.	H 2-3244 254-0110
ZIZOO, DOLLINOIS, T/IZ EIGINGII AVC	R 3-1531
	RI 1-6401
21204, 10W30H, 701 E. Joppa Ramming T. 1001 P. 017 F.	D 6-0175
	A 8-7521
	E 4-4611
MIDITIDAN 40213, Detroit, 10133, IV. Miditidials Na	U 6-7056
40234, Detroit, 11300 tast deven mile italianistic	533-1147
	625-6888
	649-9245
	IA 3-6442
	(E 4-7188
NEW JERSEY 07104, Newark, 868 Broadway	
NEW MEXICO 87110 Albuquerque 116 Washington St., East304	343-0289
4700 Lomas Blvd., N.E	R 6-7800

DIACK & DECKED CALEC AND SERVICE CENTRES

BLACK & DI	ECKER SALES AN	ID SERVICE CENT	IKES
QUEBEC, P.Q.: 3 MONTREAL, QUE.: 7 LONGUEUIL. ONT.: 1	1568 Chemin De Chambly 285 Richmond Rd. Central Avenue 729 Kennedy Road 2 Valleybrook Drive	LONDON, ONT.: WINNIPEG, ST. JAMES, MAN.: REGINA, SASK.: CALGARY, ALTA.: EDMONTON, ALTA.:	180 Parkdale Ave. North 631 Commissioners Rd. E 934 St. James St. 1076 Albert Street 1003 11th Ave., S.W. 11440 Ave 142nd Stree 24 West 2nd Avenue

CONNECTICUT, New H DELAWARE, Wilmingto FLORIDA, Pensacola IDAHO, Boise, Lewisto INDIANA, South Bend

DISTRIBUTION CENTERS

MANUFACTURING PLANTS

Lancaster, Pa.; Soion, Ohio;

Erie SOUTH CAROLINA, Charleston

stead, Md., U.S.A.;

(B-D) Quality Guarantee


"Black & Decker guarantees, for one year from date of purchase, to correct by repair or parts replacement, without charge, any defect due to faulty material of workmanship. Simply return the complete unit, transportation prepaid, to any Black & Decker Service Centre or authorized Service Station. Naturally, we assume no responsibility for damage caused by misuse, careless handling or where repairs have been made or attempted by others. No other guarantee, written or verbal, is authorized by us."

Black & Decker



This tool is protected by Rapid Exchange Service. See guarantee above.


Black & Decker POWER TOOLS



This booklet is provided for your convenience in the use and care of your new Black & Decker tool. These instructions include operation, safety precautions, preventive maintenance, maintenance and other pertinent data to assist you in assuring long life and dependable service.

4015

HEAVY-DUTY FINISHING SANDER **TYPES 1A & 2**



PARTS IDENTIFICATION 4015 H.D. FINISHING SANDER, 3.0 AMPS., 10,000 O.P.M.

Inde	ay .		ı	Inde	Y			1	Inde	v		
No		. Part Description	Quantity	No		. Part Description	Oua	intity	No.		. Part Description	Quantity
1	57005	ident sticker	1	19		lead terminal		2	38	65393	#8-32 x 21/8 FH screw	2
2	61037	motor housing	i	20		field (120V)		ī	39	975002	nameplate	ī
3	36478	attach. plug (120V)	ī			field (150V)		ī	40	3041	drive screw	$\bar{2}$
	37140	attach. plug (150-250V)	ī			field (100V)		ī	41	66181	flexible post	4
4		cord & plug (includes				field (220V)		ī	42	65427	post spacer; includes	V
		item 3) (120V)	1	21	61138	bearing retainer		ī			item 55 (2)	2
	37142	cord & plug (includes	-	22	61137	clamp		4	43	58871	base plate	1
		item 3) (150-250V)	1	23	1789	#8-32 x ½ FH screw		4			(includes 44, 45, 46,	47)
5	24288	cord protector	ī	24	30611	rubber plug		3	44	58874	spring	2
6	8033	cord clamp	1	25	67140	ball bearing		1	45	58897	bumper	2
7	7895	#8-32 x 1/4 RH screw	1	26	89559-31	armature 120V		1	46	58815	clamp	2
8	418	#8 lockwasher	12		89560-33	armature 150V		1	47	67374	roll pin	2
9	1747	lead terminal	1			armature 220V		1	48	5927-01	washer	1
10	20404	#5-40 x 3/32 term. screw	2		89559-55	armature 100V		1	49	416	1/4 lockwasher	1
11	1991	#6 lockwasher	2	27	58814	fan		1	50	10584	1/4-28 x 3/8 RH screw	1
†12	26192	lead terminal	2	28	58876	spacer		1	51	417	#10 lockwasher	4
13	49352	switch 100-120V	1	29	54301	ball bearing		2	52	34935	#10-32 x ½ screw	4
	62051	switch 150-250V	1	30	61139	bearing retainer		1	53	59998	base plate & pad	1
†14	32114	wire connector	1	31	63896	flexible coupling		1	55	66178	damper pad	4
15	1988	#8-32 x ¼ RH screw	1	32	89773	eccentric		1				
16	46210	br. hold plug	2	33	61140	spring		2	Parts	Not Sho	wn	
17	46211	brush assembly 100-120\	1 2	34	61038	cover housing		1		59633 cc	onnection diagram	
	50946	brush assembly 150-250\		35	379	#8-32 x 3/4 FH screw	& w	1				
18	61208	brush holder	2	36	640	#8-32 x 1 FH screw		1				
† 0	mit on 150,	220, and 240 volt units.	,	37	99410-38	#8-32 x 2% FH screv	V	3				

WHEN ORDERING REPLACEMENT PARTS, YOU MUST GIVE UNIT, TYPE AND CATALOG NUMBER AS SHOWN ON NAMEPLATE, PLUS PART NUMBER AND NAME OF PART NEEDED.

MOTOR:


Your Black and Decker tool is powered by a B&D built "Universal" motor. It operates, at nameplate voltage on Alternating Current (25 to 60 cycles) or on Direct Current. Voltage variation of more than 10% will cause loss of power and overheating. All B&D tools are factory-tested; if this tool does not operate, check the following: Supply line for blown fuses; plug and receptacle for contact; carbon brushes.

COMMUTATOR AND BRUSHES:

Inspect carbon brushes often. Replace when brushes are worn down to identifying letter or groove or when spring exerts insufficient pressure to hold brush against commutator. Keep brushes clean and sliding freely in guides. Inspect commutator for dirt and excessive wear. If dirty or rough, clean **lightly** with very fine sandpaper (**not emery cloth**). If badly worn or grooved, send tool to our nearest service station for repair (see back page).

GROUNDING:

These units are equipped with approved 3-conductor cord and 3-blade grounding type attachment plug cap to be used with the proper grounding type receptacle, in accordance with the Canadian Electrical Code.



CABLE:

The cable is the "life line" of your tool — keep it clean by wiping it off occasionally. Keep it out of oils and greases which ruin the rubber. Coil it neatly when not in use and avoid dragging it across sharp surfaces or using it as a handle to lift the tool.

Ampere rating (on nameplate)	0 to 2.0	2.10 to 3.4	3.5 to 5.0	5.10 to 7.0	7.10 to 12.0	12.1 to 16.0
Ext. Cable length			Wire Size	(A.W.G.)		L
25 ft.	18	18	18	18	16	14
50 ft.	18	18	18	16	14	12
75 ft.	18	18	16	14	12	10
100 ft.	18	16	14	12	10	_
150 ft.	16	14	12	12		_
200 ft.	16	14	12	10		l

When using the tool at a considerable distance from power source, an extension cable of adequate size must be used to prevent loss of power and over-heating. Use the table below for 120 volt tools. For 220 volt tools, use wire size corresponding to an extension length of $\frac{1}{2}$ the contemplated length.

SAFETY PRECAUTIONS:

- 1. ALWAYS BE SURE THAT THE TOOL IS PROPERLY GROUNDED.
- 2. BEFORE MAKING ANY ADJUSTMENTS, ATTACHING ABRASIVE PAPER, INSPECTING, CHANGING BRUSHES, OR AT ANY TIME TOOL IS NOT IN USE, BE SURE THAT THE SWITCH IS IN THE "OFF" POSITION AND THAT THE TOOL HAS BEEN DISCONNECTED FROM THE POWER SUPPLY.

SWITCH:

These tools are equipped with a trigger switch and locking pin. To start tool, depress trigger; to stop tool, release trigger. To lock trigger in "ON" position for continuous operation, depress trigger, push in locking pin (located next to trigger), and release trigger. To release locking mechanism and turn tool "OFF", depress and release trigger.

LUBRICATION:

This tool has been completely lubricated at the factory and is ready for use. No further periodic lubrication is necessary. All bearings are closed type, grease sealed ball bearings which require no lubrication.

ATTACHING ABRASIVE PAPER:

- 1. UNPLUG TOOL FROM POWER SUPPLY.
- 2. DEPRESS CLAMP AND HOLD IN OPEN POSITION (see Fig. 2, on back cover), INSERT PAPER AND RELEASE CLAMP.
- 3. DRAW PAPER TIGHT ACROSS PAD TOWARD BACK OF UNIT AND REPEAT SAME OPERATION AS ABOVE.

ACCESSORY AND REPLACEMENT PARTS FOR NO. 4015 SANDER

Model No. 59991. Felt Pad and Plate is available for use as an accessory or replacement part. Model No. 59998. Rubber Pad and Plate (standard with the No. 4015 Sander).

ABRASIVE PAPER 41/2" x 11" size

U1416 60 grit **U1417** 100 grit

U1418 150 grit